

GAS CHROMATOGRAPHY

Gas chromatography is a technique used for separation of volatile substances, or substances that can be made volatile, from one another in a gaseous mixture at high temperatures. A sample containing the materials to be separated is injected into the gas chromatograph. A mobile phase (carrier gas) moves through a column that contains a wall coated or granular solid coated stationary phase. As the carrier gas flows through the column, the components of the sample come in contact with the stationary phase. The different components of the sample have different affinities for the stationary phase, which results in differential migration of solutes, thus leading to separation

Gas chromatography can be used for both qualitative and quantitative analysis. Comparison of retention times can be used to identify materials in the sample by comparing retention times of peaks in a sample to retention times for standards. The same limitations for qualitative analysis

There are two types of Gas chromatography

Gas - Solid Chromatography (GSC)

Gas - Liquid Chromatography (GLC)

Gas - Solid Chromatography (GSC)

The stationary phase, in this case, is a solid like silica or alumina. It is the affinity of solutes towards adsorption onto the stationary phase which determines, in part, the retention time. The mobile phase is, of course, a suitable carrier gas. This gas chromatographic technique is most useful for the separation and analysis of gases like CH_4 , CO_2 , CO , ... etc.

Gas - Liquid Chromatography (GLC)


The stationary phase is a liquid with very low volatility while the mobile phase is a suitable carrier gas. GLC is the most widely used technique for separation of volatile species. The presence of a wide variety of stationary phases with contrasting selectivities and easy column preparation add to the assets of GLC or simply GC.


Gas Chromatography (GC)

*Gas chromatography is a chromatographic technique that can be used to separate volatile organic compounds.

*It consists of

- ✓ a flowing mobile phase
- ✓ an injection port
- ✓ a separation column (the stationary phase)
- ✓ an oven
- ✓ a detector.





Principle

The organic compounds are separated due to differences in their partitioning behavior between the mobile gas phase and the stationary phase in the column.


✓ Mobile phases are generally inert gases such as helium, argon, or nitrogen.

✓ The injection port consists of a rubber septum through which a syringe needle is inserted to inject the sample.

✓ The injection port is maintained at a higher temperature than the boiling point of the least volatile component in the sample mixture.


✓ Since the partitioning behavior is dependent on temperature, the separation column is usually contained in a thermostat-controlled oven.

✓ Separating components with a wide range of boiling points is accomplished by starting at a low oven temperature and increasing the temperature over time to elute the high-boiling point components.



A gas chromatography oven, open to show a capillary column

Gas Supply




- The mobile phase (carrier gas) should be chemically inert, dry and free from O₂ (helium, argon, nitrogen and hydrogen).
- The carrier gas should be of high purity; impurities in the carrier gas such as water vapour, air and trace gaseous hydrocarbons can cause reactions with sample and cause column deterioration and affect detector performance.
- The gas supply is associated with pressure regulator and flow controller.

Sample Injection System

Preparation of the Sample :

Samples GC must be volatile.

Samples which are non volatile are converted into a volatile derivative.



GC Column

Most GC columns are made from high-purity fused silica capillary, the inner wall of the capillary coated with the stationary phase.

GC columns vary in length from less than 2 m to 50 m or more.

In order to fit into the column oven, they are usually formed as coils.

The control of column's temperature is critical to attain a good separation in GC, thus the column is located inside a thermostated oven to control the temperature.

GC Detectors

- Thermal conductivity detector (TCD)
- Flame ionization detector (FID)
- Nitrogen phosphorous detectors (NPD)

GC Applications:

Food Analysis

Analysis of foods is concerned with confirming the presence and determination the quantities of the analytes (lipids, proteins, carbohydrates, preservatives, flavours, colorants, and also vitamins, steroids, and pesticide residues).

Drug Analysis

GC is widely applied to identification of the active components, possible impurities as well as the metabolites.

Environmental Analysis

The environmental contaminants; e.g. (DDT) is present in the environment at very low concentrations and are found among many of other compounds. GC, with its high sensitivity and high separating power, is mostly used in the analysis of environmental samples.

Forensic Analysis


In forensic cases, very little sample is available, and the concentration of the sample components may be very low. GC is a useful due to its high sensitivity and separation efficiency.

Comparison of HPLC and GC

Sample Volatility

HPLC

- No volatility requirement
- Sample must be soluble in mobile phase



GC

- Sample must be volatile

Sample Polarity

HPLC

- Separates both polar and non polar compounds

GC

- Samples are nonpolar and polar

Comparison of HPLC and GC

Sample Preparation

HPLC

- Sample must be filtered
- Sample should be in same solvent as mobile phase

GC

- Solvent must be volatile and generally lower boiling than analytes

Sample Size

HPLC

- Sample size based upon column.

GC

- Typically 1 - 5 μL

Comparison of HPLC and GC

Separation Mechanism

HPLC

- Both stationary phase and mobile phase take part



GC

- Mobile phase is a sample carrier only

Detectors

HPLC

- Most common UV-Vis
- Wide range of non-destructive detectors
- 3-dimensional detectors

GC

- Most common FID, universal to organic compounds

Thank you

